



REPTISUN® T5 HO HIGH OUTPUT TERRARIUM HOOD

ITEM # LF-70

INSTRUCTIONS

Congratulations on your purchase of Zoo Med's REPTISUN® T5 HO TERRARIUM HOOD! The following instructions will assist you with the proper set-up and operation of this unit. Please read the following instructions carefully. If you have any questions regarding these instructions or the proper use of this item, please contact our customer service department at:

email: zoomed@zoomed.com

website: www.zoomed.com

Or by calling (888) 496-6633 (US and Canada only).

Customers in other countries, please call (805) 542-9988.

FEATURES:

• LOW PROFILE DESIGN

• INCREASED LIGHT & UV OUTPUT:

- Use with Zoo Med ReptiSun® T5 HO lamps to provide safe & effective UVB for your reptiles.
- Stronger UVB & brighter light: twice as strong compared to standard T8 lamps.
- Highly polished curved reflector for increased lamp efficiency.

• FOR USE WITH THE FOLLOWING LAMPS*:

- ReptiSun® 5.0 T5 High Output - 15 watt / 12" (Item FS5-15)
- ReptiSun® 10.0 T5 High Output - 15 watt / 12" (Item OS5-15)

SAFETY INSTRUCTIONS:

IMPORTANT: In order to reduce the risk of fires or electric shock, read and save these instructions prior to operation.

- DO NOT exceed electrical rating.
- DO NOT splice, repair, or modify. Fully extend cord before using.
- DO NOT use in wet conditions. Use indoors only. Not for use with aquariums.
- Keep children and pets (other than your terrarium animals) away from fixture.
- Fully insert plug. Unplug power cord before inserting or changing bulb.
- DO NOT cover with blankets, rugs or any material.
- DO NOT use damaged cord sets – inspect periodically.
- DO NOT alter or modify this product. Contact an electrician if you are unsure about the electrical connection.
- This unit has no user-serviceable parts. Do not attempt to examine or repair this product yourself. Return to Zoo Med for inspection and repair.

WARNING! RISK OF FIRE:

Read and save all safety instructions before operating lamp fixture.

IMPORTANT: This appliance has a GROUNDED plug for safety and must be plugged into a grounded receptacle. Do not modify the plug in any way.

CAUTION:

ReptiSun® UVB lamps emit UV radiation and must be used in accordance with these instructions. Just as you would not stare into the sun, do not stare into this lamp! This lamp must be placed directly overhead of your reptiles, and not to the side which would force them to stare into the lamp. **Always have your lamp at least six inches away from your reptiles.** Failure to use this lamp according to these instructions may result in personal injury or may cause injury to your reptile(s).

OPERATING INSTRUCTIONS:

Zoo Med's ReptiSun T5 High Output Terrarium Hood is designed to fit terrariums 14 inches wide and up. This hood can hold one 15 watt / 12" ReptiSun T5 HO Fluorescent UVB lamp. See below to determine which lamp is best for your animals.



ReptiSun® 5.0 T5 High Output - 15 watt / 12" (Item FS5-15)

- Designed for use with **tropical & temperate reptiles** in terrariums that are up to 18" tall.
- Ideal for use with the following species:
 - Tropical lizards (Green Iguanas, Day Geckos, Anoles, Water Dragons)
 - Aquatic Turtles, Box Turtles, & Tortoises
 - Old-world Chameleons (Panther Chameleons, Veiled Chameleons, Jackson's Chameleons, etc.)



ReptiSun® 10.0 T5 High Output - 15 watt / 12" (Item OS5-15)

- Designed for use with **desert reptiles** in terrariums that are up to 30" tall.
- Ideal for use with the following species:
 - Bearded Dragons
 - Uromastyx
 - Monitors & Tegus
 - Other desert reptile species

1. Select the appropriate lamp from the list above (lamp sold separately).
2. Be sure that lamp is unplugged when removing or installing the lamp.
3. Install lamp into fixture by inserting pins into lampholders and rotating the lamp one quarter turn.
4. Place the fixture on the top of the terrarium above the screen cover.
5. Fully insert plug into power outlet.
6. Turn fixture on using the on/off switch located on the back of the fixture near the power cord.

WHY YOUR REPTILES NEED UVB AND UVA LIGHTING:

UVB: Reptiles need UVB for vitamin D production and calcium metabolism. Without UVB, reptiles can develop Metabolic Bone Disease in 6 months or less. UVB along with proper temperatures, will enable your reptiles to make vitamin D and process calcium from their diet.

UVA: Reptiles and amphibians can see things that humans can't. UVA is part of the rainbow of colors that reptiles can see. UVA helps to increase activity levels, appetite, and reproductive behaviors. Without UVA, they are colorblind!

IMPORTANT NOTES: Fine mesh blocks up to 50% of light and UVB. This should be taken into consideration when determining lamp distance. Glass and plastic filter out UVB; there should be no glass or plastic between the lamp and your reptile. **Always have your lamp at least six inches away from your reptiles.**

WHEN TO REPLACE YOUR LAMP: This lamp will provide your animals with beneficial UVB for a period of 12 months when used 10 to 12 hours per day. Record date of first use on lamp and replace after 12 months. Use Zoo Med's "UVB Reminder" tool online at www.zoomed.com.

WARRANTY:

Zoo Med Laboratories, Inc. (Zoo Med) warrants this product to be free of defects in material and workmanship under normal use and service for one year from the date of purchase. The obligation under this warranty is limited to the repair or replacement, at Zoo Med's discretion, of the product or any part thereof, when the product is returned to Zoo Med, freight prepaid. No claim shall be allowed under this warranty if, in the opinion of Zoo Med, this product has been subject to accident or improper usage, including but not limited to: water damage, improper storage, accidental dropping, etc. This warranty is in lieu of all other warranties and representations express or implied. Please include your receipt, full name, address, phone number, and email address along with a note explaining failure when sending any product back to Zoo Med. Please allow 4 to 6 weeks for repair or replacement.

America's Premier Manufacturer of Exotic Pet Products Since 1977



ZOO MED LABORATORIES
3650 SACRAMENTO DR.
SAN LUIS OBISPO CA 93401
PHONE: 805-542-9988
TOLL FREE: 888-496-6633
www.zoomed.com

**please email or call us with any questions you may have.
email: zoomed@zoomed.com*